

Current Clamp Compatibility Chart

	12	16	110/111/112	175/177/179	187/189	27	45	73 III	77 III	78	83V/87V	88V	43B	430 Series	120 Series	190 Series	1577 / 1587	715	724	725	741B/743B/744	787	789
AC Models																							
i5s														●									
i200				●	●	●	●	●	●	●	●	●					●					●	●
i200s	●	●		●	●	●	●	●	●	●	●	●	●	●	●	●	●				●	●	●
i400				●	●	●	●	●	●	●	●	●					●					●	●
i400s	2	2		2	2	2	2	2	2	2	2	2	●	●	●	●	2				2	2	2
i1000s	2	2		2	2	2	2	2	2	2	2	2	●	●	●	●	2				2	2	2
i2000flex	●	●		●	●	●	●	●	●	●	●	●	●	●	●	●	●				●	●	●
i3000s	●	●		●	●	●	●	●	●	●	●	●	●	●	●	●	●				●	●	●
AC/DC Models																							
80i-110s	2	2		2	2	2	2	2	2	2	2	2	●	●	●	●	2				2	2	2
i410	●	●	1	●	●	●	●	●	●	●	●	●			3	3	●	1	1	1	●	●	●
i1010	●	●	1	●	●	●	●	●	●	●	●	●			3	3	●	1	1	1	●	●	●
Other																							
90i-610s*	2	2		2	2	2	2	2	2	2	2	2	●	●	●	●	2				2	2	2
CS20MA															●	●							
700 IV																					●		

* For specifications of 90i-610s see page 79

1 For DC only

2 Requires PM 9081 (see page 61)

3 Requires PM 9082 (see page 61)